


KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENENCE SPECIAL TOOLS KIT

BOX 1 LAYER 1




#	P/N	DESCRIPTION	QTY	U/I
LAYER 1				
1	SPX J23479-E	REMOVER, VALVE, SEAT	1	EA



KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENENCE SPECIAL TOOLS KIT


BOX 1 LAYER 2



#	P/N	DESCRIPTION	QTY	U/I
LAYER 2				
2	SPX J28454	TEST FIXTURE, CYL HD	1	SE
3	SPX J22525-B	INJECTOR, TUBE, RECON	1	SE
4	DRF 26899	FIXTURE, PTO GEAR	1	SE
5	SPX J24563-A	REMOVER, LNR, CYL SET	1	SE
5A	BEARING	THRUST BEARING	1	EA
5B	J-24563-4	BRIDGE ASSEMBLY	1	EA
5C	J-24563-11	CAP SCREW	1	EA
5D	HEX NUT	HEX NUT	1	EA
5E	J-24563-6	UPPER SHOE	1	EA
5F	J-24563-12	LOWER SHOE AND LOCK BOLT ASSY	1	EA

KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENECE SPECIAL TOOLS KIT

BOX 2 LAYER 1




#	P/N	DESCRIPTION	QTY	U/I
LAYER 1				
1	SPX J-24310	FIXTURE, HOLDING	1	EA



**KIT PLS
PALLETIZED LOAD SYSTEM (PLS)
FIELD LEVEL MAINTENECE SPECIAL TOOLS KIT**


BOX 2 LAYER 2



#	P/N	DESCRIPTION	QTY	U/I
LAYER 2				
2	DRF 39929	ADAPTER, AXLE CARRIER	1	EA

KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENENCE SPECIAL TOOLS KIT

BOX 3 LAYER 1




#	P/N	DESCRIPTION	QTY	U/I
1	DRF 737	TSTG KIT, PRSR, BLK	1	SE
1A	2BF928	T-HANDLE	2	EA
1B	45152	PLATE	1	EA
1C	737	COLLAR	20	EA
1D	2AW57C	PLATE	2	EA



KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENENCE SPECIAL TOOLS KIT

BOX 4 LAYER 1




#	P/N	DESCRIPTION	QTY	U/I
LAYER 1				
1	SPX J33850	ADAPTER, ENG, STAND	1	EA



KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENENCE SPECIAL TOOLS KIT


BOX 4 LAYER 2



#	P/N	DESCRIPTION	QTY	U/I
LAYER 2				
2	DRF 24208D	SNAP RING ASSEMBLY	1	SE
2A	J-24208-2	CYLINDER	1	EA
2B	J-24208-3	BAR	1	EA
2C	J-24208-1	BOLT 1	1	EA
2D	J-24208-4	BOLT 2	2	EA
2E	J-24208-5	BOLT 3	2	EA
2F	J-24208-25	ROD 1	1	EA
2G	J-34127	ROD 2	1	EA
MISC		HARDWARE FOR J33850	1	PG

KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENECE SPECIAL TOOLS KIT

BOX 5 LAYER 1




#	P/N	DESCRIPTION	QTY	U/I
LAYER 1				
1	STA 84Z-111-5J	BORE GAGE, 3" - 5-3/16", 6" BORE DEPTH	1	SE
2	ATG CA105020/25-30-0003	FAULT, RETRIEVAL DEVICE	1	EA
3	TWG A370101	TETSTER, OSS	1	EA



KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENECE SPECIAL TOOLS KIT


BOX 5 LAYER 2



#	P/N	DESCRIPTION	QTY	U/I
LAYER 2				
4	DRF 1764	TOOL SET, BUSHING, EQUAL	1	SE
4A	206459	CLAMP PLATE, BUSHING	1	EA
4B	204657	PRESS ADAPTOR, BUSHING	1	EA
4C	42052	CLAMP	1	EA
4D	302030	REMOVING ADAPTOR, BUSHING	1	EA
5	DRF 34930	TOOL, TIMING	1	EA

KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENECE SPECIAL TOOLS KIT


BOX 5 LAYER 3



#	P/N	DESCRIPTION	QTY	U/I
LAYER 3				
4E	302027	REMOVING ADAPTOR, BUSHING	1	EA
4F	302026	INSERTER BEARING & BUSHING	1	EA
4G	51110	PRESS PLATE BUSHING	1	EA
4H	302032	ADAPTER REMOVER	1	EA
4I	302031	ADAPTER, INSTALLING	1	EA

KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENECE SPECIAL TOOLS KIT


BOX 6 LAYER 1



#	P/N	DESCRIPTION	QTY	U/I
LAYER 1				
1	DRF 8165-2	GAGE, DIAL, VALVE SEAT	1	EA
2	DRF 7455	COMPRESSOR, SPRING, VALVE	1	EA
3	DRF 24453	INSTALLER, LOCK RING	1	EA
4	STA 247B	BALL ATTACHMENT MICROMETER	1	EA
5	DRF 24315	PIN, GUIDE SET	1	SE
5A	DRF 24315-2	GUIDE PIN	1	EA
5B	DRF 24315-5	GUIDE PIN	1	EA
5C	DRF 24315-4	GUIDE PIN	1	EA
5D	DRF 24315-3	GUIDE PIN	1	EA
5E	DRF 24315-6	GUIDE PIN	1	EA
5F	DRF 24315-1	GUIDE PIN	1	EA
6	DRF 33095	REMOVER, ELECTRICAL CONTACT	1	EA
7	DRF 34650	REMOVER/INSTALLER, PLUG	1	EA
8	WWM SBH945	PLIERS, RETAINING RING	1	EA
9	DRF 8128	REMOVER AND REPLACER	1	EA
10	DRF 21100	WRENCH SET, PUSHROD	1	SE
11	DRF 9708	GAGE, THICKNESS	1	EA
12	KAS FG-9	THICKNESS GAGE	2	EA
13	STP 4988CF	WRENCH, CROWFOOT, 3/8 DR, 2-3/4 OE	1	EA
14	DRF 5437	CLEANER, VALVE GUIDE	1	EA
15	CRE CW24	WRENCH 24 CHAIN	1	EA

KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENENCE SPECIAL TOOLS KIT

BOX 6 LAYER 2



KIT PLS

PALLETIZED LOAD SYSTEM (PLS)

FIELD LEVEL MAINTENECE SPECIAL TOOLS KIT


BOX 6 LAYER 2

#	P/N	DESCRIPTION	QTY	U/I
LAYER 2				
16	DRF 24898	GAGE, CYLINDER	1	EA
17	DRF 6125-1B	HAMMER, SLIDE TYPE	1	EA
18	DRF 6569	REMOVER, VALVE GUIDE	1	EA
19	DRF 7482	INSTALLER, VALVE BRI	1	EA
20	DRF 24411	INSTALLER, PLUG	1	EA
21	DRF 24369	INSTALLER, PLUG	1	EA
22	DRF 25502	GAGE, INJECTOR	1	EA
23	DRF 33765	ADAPTER, ELECT RECPT	1	EA
24	DRF 25562	INSERTER, BEARING/BUSHING	1	EA
25	DRF 39815	ALIGNMENT TOOL, ELECTRIC	1	EA
26	DRF 8501	INSTALLER, SEAL, OIL	1	EA
27	DRF 25002	STUD SET (SET OF 2)	1	SE
28	DRF 7872	DIAL, INDICATOR, MAG	1	EA
29	DRF 818	WRENCH, FUEL LINE NUT	1	EA
30	DRF 24599	GAGE, GROOVE	1	EA
31	DRF 33001	TOOL ALIGNMENT	1	EA
32	DRF 7932	REMOVER, PULLEY	1	EA
33	DRF 8682	EXPANDER, SEAL, OIL	1	EA
34	DRF 21850	INSTALLER, PLUG	1	EA
35	DRF 852	REMOVER, VALVE PIN	1	EA
36	DRF 7453	REMOVER, GUIDE, BRDG	1	EA
37	DRF 38858	INSTALL TOOL, SEAL	1	EA
38	DRF 24597	INSTALLER, PLUG	1	EA
39	JOH 700	LEVEL PROTRACTOR	1	EA
40	DRF 26901	PULLER, BEARING	1	EA
41	DRF 9791	INSTALLER, SEAL, OIL, COVER	1	EA
42	DRF 29198-3	GAGE, CENTER & POINT	1	EA



KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENECE SPECIAL TOOLS KIT


BOX 6 LAYER 3



#	P/N	DESCRIPTION	QTY	U/I
LAYER 3				
43	DRF 24357	INSTALLER, SEAT VALVE	1	EA
44	DRF 33079	PULLER, MECHANICAL	1	EA
45	PFM HDT-48-00	DEUTSCH TERMINAL CRIMP TOOL	1	EA
46	DRF 21520	INSTALLER, GUIDE, VALVE	1	EA
47	DRF 23762	INSTALLER, RETAINER, PISTON	1	EA
48	DRF 496	DRIVER	1	EA
49	DRF 129	SPANNER ATTACHMENT	1	EA
50	STP 1264	WR COMB 2 12 PT	1	EA
51	DRF 24219	COMPRESSOR, SPRING	1	EA
52	DRF 7091	REMOVER KIT, GUIDE VALVE	1	SE
52A	7091-01D	BUSHING	1	EA
53B	7091-01A	BUSHING	1	EA
52C	7091-01B	SCREW	1	EA
52D	7091-01C	COLLAR	1	EA
52E	7091-01E	SET SCREW	1	EA
53	DRF 25275	REMOVER/INSTALLER, ADAPTER	1	EA
54	DRF 23019	INSTALL/REMOVE TOOL	1	EA
55	DRF 9783	INSTALLER, SEAL	1	EA
56	SET 50	COMPRESSOR, PISTON RING	1	EA
57	SPX J-23987-B	TESTER, VACUUM GAGE	1	EA

KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENECE SPECIAL TOOLS KIT


BOX 6 LAYER 4



#	P/N	DESCRIPTION	QTY	U/I
LAYER 4				
58	DRF 546	INSTALLER, SEAL, THERMAL	1	EA
59	DRF 24202-4	HANDLE, DRIVER	1	EA
60	CON 5120-01-354-9452	SOCKET WRENCH, FACE	1	EA
61	DRF 24216-01	PROTECTOR, SEAL, CL	1	EA
62	STP 075903/4	SKT IMP HEX BIT 3/4 DR 3/	1	EA
63	STP 075905/8	SKT IMP HEX BIT 3/4 DR 5/	1	EA
64	STP 1268	WR COMB 2-1/8 12 PT	1	EA
65	DRF 28557	REMOVER, BEARING	1	EA
66	STP 54415/16	SKT HEX BIT 1/2 DR 5/16	1	EA
67	STP 54419/16	SKT HEX BIT 1/2 DR 9/16	1	EA
68	CON 5120-01-386-5999	SOCKET, 55MM	1	EA
69	CON 5120-01-386-5988	SOCKET, 63MM	1	EA
70	DRF 24200	INSTALLER AND STAKE	1	SE
70A	24200	INTALLER	1	EA
70B	24200-A	STAKE	1	EA
71	DRF 24285	TOOL, ALIGNMENT PISTON, PIN	1	EA
72	CON 5120-00-219-8397	PULLER, MECHANICAL	1	EA

KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENENCE SPECIAL TOOLS KIT

BOX 7 LAYER 1




#	P/N	DESCRIPTION	QTY	U/I
LAYER 1				
1	CON 5120-00-629-9781	FLYWHEEL, ALIGNING STUDS,	1	SE
2	SPX J35689-A	REMOVER, TERMINAL	1	EA
3	SPX J36400-5	REMOVER, TERMINAL	1	EA
4	DRF 24218-2	INSTALLER, SPRING ROLL	1	EA
5	PFM 91019-3	EXTRACTION TOOL, TYCO/AMP	1	EA
6	PFM 305183	TYCO/AMP EXTRACTION TOOL	1	EA
7	PFM 114010	DEUTSCH 12 GAUGE TERMINAL REMOVAL TOOL	1	EA
8	WWM 7958	BLADE, THICKNESS GAGE	1	EA
9	PEI 070306-0000	INSERTER, ELECTRICAL CONTACT	1	EA



KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENECE SPECIAL TOOLS KIT


BOX 7 LAYER 2



#	P/N	DESCRIPTION	QTY	U/I
LAYER 2				
10	PFM 12014254	DELPHI WEAHTERPACK TERMINAL CRIMPER	1	EA
11	PFM 8913440	DELPHI PACKARD TERMINAL CRIMPER, 56/58/5	1	EA
12	PFM 12039500	DELPHI TERMINAL CRIMPER, METRI-PAC 150	1	EA
13	MISC	PARTS FOR PFM12039500	1	EA
14	CHT IN-015	LINEAR SCALE, BRASS, IN SERIES, 15 LB X	1	EA
15	PEI SSI-CS10	CRIMPING TOOL, TERMINAL	1	EA

KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENECE SPECIAL TOOLS KIT


BOX 7 LAYER 3



#	P/N	DESCRIPTION	QTY	U/I
LAYER 3				
16	SMI 12-270	TESTER RADIATOR PRESSURE	1	EA
17	SMI 12450	ADAPTER, RADIATOR	1	EA
18	CON 5180-00-611-7945	KIT, TOOL,BLOWER	1	SE

KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENECE SPECIAL TOOLS KIT

BOX 8 LAYER 1




#	P/N	DESCRIPTION	QTY	U/I
LAYER 1				
1	DRF 35373	INSTALLER, SEAL, OIL, GDE	1	EA
2	DRF 24748	STUD SET, CYLINDER HEAD GUIDE	1	SE
3	DRF 3154	HANDLE, DRIVER	1	EA
4	DRF 551-01	HANDLE, DRIVER	1	EA
5	DRF 551	HANDLE, DRIVE TRANSMISSION	1	EA
6	DRF 371	TENSION METER, DIAL INDICATING	1	EA
7	DRF 900	FIXTURE, HLDG, GEAR	1	SE
7A	2BF712	PLATE 1	1	EA
7B	2BF710	PLATE 2	1	EA
7C	2BF711	PLATE 3	1	EA



KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENENCE SPECIAL TOOLS KIT


BOX 8 LAYER 2



#	P/N	DESCRIPTION	QTY	U/I
LAYER 2				
8	DRF 227	EXTRACTOR, KING PIN	1	EA
9	DRF 21112	SEAL INSTALLER	1	SE
9A	21112-A	PLATE	1	EA
9B	21112-B	STUD	2	EA
10	DRF 225	COVER, PRELOAD	1	SE
10A	225-B	BOLT	1	EA
10B	225-A	COVER PLATE	1	EA
11	DRF 24408	SLEEVE	1	EA
12	DRF 24209	FIXTURE, LIFTING	1	EA
13	DRF 5356	PULLEY REMOVER	1	EA
14	DRF 24198	INSTALLER, SHIELD, DUST	1	EA

KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENECE SPECIAL TOOLS KIT


BOX 8 LAYER 3



#	P/N	DESCRIPTION	QTY	U/I
LAYER 3				
15	DRF 4239	EXPANDER, SEAL	1	EA
16	DRF 21983	INSTALLER, SLEEVE	1	EA
17	DRF 24204-3	SPRING COMPRESSOR	1	EA
18	DRF 24210	PROTECTOR, SEAL, INNE	1	EA
19	DRF 233	SEAL DRIVER, CTIS	1	EA
20	DRF 228	SOCKET, SPINDLE	1	EA
21	DRF 232	SEAL DRIVER, CTIS	1	EA
22	DRF 24197	INSTALLER, BEARING	1	EA
23	DRF 6227	INSTALLER T/C SEAL	1	EA
24	DRF 25257	INSTALLER, GEAR, WATER PUMP	1	EA
25	DRF 24227	COMPRESSOR, PISTON RING	1	EA
26	DRF 26598	REMOVERJ/INSTALLER, RING, SNAP	1	EA
27	DRF 226	HAMMER, SLIDE	1	EA

KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENENCE SPECIAL TOOLS KIT

BOX 9 LAYER 1




#	P/N	DESCRIPTION	QTY	U/I
LAYER 1				
1	DRF 24565-02	BRACKET, MOUNTING	1	SE
1A	24545-B1	BRACKET	3	EA
1B	WASHER	WASHER	6	EA
1C	BOLT	MACHINE BOLT	6	EA
2	DRF 39911	ADAPTER KIT, TRANSFER	1	SE
2A	BOLT	BOLTS FOR 39911	4	EA
3	DRF 22273	GAGE, DEPTH	1	EA
4	DRF 2HP645	PULLER, PUMP, DSM	1	EA



KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENECE SPECIAL TOOLS KIT

BOX 9 LAYER 2



#	P/N	DESCRIPTION	QTY	U/I
LAYER 2				
5	DRF 24202-1A	INSERTER, TRANSMISSION OIL SEAL	1	EA
6	DRF 25007A	SLEEVE	1	EA
7	DRF 24204-1	COMPRESSOR RING	1	EA
8	DRF 234	GUIDE SLEEVE, CTIS	1	EA
9	DRF 12379637	SOCKET WRENCH, FACE	1	EA
10	DRF 24221	FIXTURE, ALIGNMENT	1	EA
11	DRF 12379638	SOCKET WRENCH, FACE	1	EA
12	DRF 24365	BRACKET, LEFTG, FLYWHEEL	1	EA
13	DRF 24195	LIFTING BRACKET, CEN	1	EA
14	DRF 24196	BRACKET, LIFTING	1	EA

KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENENCE SPECIAL TOOLS KIT

BOX 10 LAYER 1




#	P/N	DESCRIPTION	QTY	U/I
1	VES LO-J	STABILIZING JACK	1	EA



KIT PLS PALLETIZED LOAD SYSTEM (PLS) FIELD LEVEL MAINTENECE SPECIAL TOOLS KIT

BOX 11 LAYER 1



#	P/N	DESCRIPTION	QTY	U/I
1	JGB 4940-01-046-7109	CHARGING KIT, PRESSURE	1	EA

